

***CARE AND MAINTENANCE FOR  
“CHRIS & CHRIS”  
BUTCHER BLOCK SURFACES***

DO NOT ALLOW MOISTURE OF ANY KIND TO STAND ON WOOD SURFACE FOR LONG PERIODS OF TIME.

BUTCHER BLOCK SURFACE SHOULD BE THOROUGHLY CLEANED AFTER EACH USE WITH A WELL WRUNG, MOIST SOAPY TOWEL , CLOTH, OR ANTIBACTERIAL SOAP OR WIPES. AVOID THE USE OF HARSH CHEMICALS OR ABRASIVE MATERIALS TO CLEAN THE SURFACE OF THE BUTCHER BLOCK AS THESE MAY HARM THE NATURAL WOOD SURFACE. OR ANTIBACTERIAL SOAP OR WIPES

BE SURE THAT THE WOOD SURFACE IS DRIED COMPLETELY AFTER USE AND / OR CLEANING TO PREVENT WARPING, CRACKING, AND SEPARATION.

THE SURFACE OF THE BLOCK SHOULD BE TREATED BEFORE USE WHEN NEW AND PERIODICALLY THEREAFTER WITH A “FOOD GRADE” MINERAL OIL (BLOCK OIL)TO HELP PREVENT BACTERIAL PENETRATION AND TO ALLOW FOR EASY CLEAN UP.